

TE-210A / TE-510A User Menu

- **Key Define:**

Numeric 0 ~ 9

DEL


ESC

↑ (UP)

↓ (DOWN)

ENTER

- **Connect Define:**



Power


Ext.Key

RS232

- **User's Menu:**

1. Send a page:

- 1.1. Enter Pager No# or Name



Enter pager number & message then press **ENTER** to send,
PageTo no# : 1 ~ 899

900 ~ 999 as group call

- 1.2. Edit Message:



Entering Proprogramming Message, press **↑** or **↓** with
01~99 on the keypad

Max. message length = 60

- 1.3. Sending:

By pressed **ENTER**



2. Press **ESC** to advance to the Administration Menu

Enter Password

Enter Password
* * * * █

ENTER default password “ 1234 ”

2.1. The Administration Menu:

SELECT OPTION:
1. Edit Pagers
2. Enter New Time
3. View Last Message
4. Range Test Mode
5. Edit Alarm Message
6. View Alarm Status
7. Edit PPG Message
8. Clear All Data
9. Protocol Type Sel.
0. Frequency Setting
A. HeartBeat Setup
B. Factory Setup

Press **↑** or **↓** to move cursor up or down. Press **ENTER** to into the item

2.2. Edit Pagers

PAGER TO EDIT:210 █
Enter Pager No#

2.2.1. Edit Pagers menu

210 ▼
 CAPCODE
 PAGER TYPE A
 BAUD RATE 1200
 FUNCTION BIT 0
 NAME
 PAGER GROUP
 DELETE
 SAVE & EXIT

Pager no#

2.2.1.1. CAPCODE

ENTER CAPCODE:
■
Range = 8 ~ 2097151

2.2.1.2. PAGER TYPE

SELECT PAGER TYPE:
ALPHA TYPE
NUMERIC TYPE
DELETE

2.1.1.3. BAUD RATE

SELECT BAUD RATE:
512 bps
1200 bps
2400 bps

2.1.1.4. FUNCTION BIT

ENTER FUNCTION BIT:
■
Range = 0 ~ 3

2.1.1.5. NAME

ENTER NAME:
■
Max. 10 Characters

2.1.1.6. PAGER GROUP

ENTER PAGER GROUP:
█
Range = 00 ~ 99

2.1.1.7. DELETE

2.1.1.8. SAVE & EXIT

2.2. Enter New Time

SET TIME
12:00PM

2.3. View Last Message

LAST MESSAGE: 210
This is the Message
Body!

PageTo Number

Last Message
Body

2.4. Range Test Mode


RANGE TEST MODE
MSG: RANGE TEST 001
PAGER ID: 100
PAGING COUNT DOWN: 10

Message Content

Page to #100

Sending counter

2.5. Edit Alarm Message



PageTo no#

Press **ENTER** to Edit Alarm Message

2.5.1. Edit




2.6. View Alarm Status



"1" is active; "0" is no active

2.7. Edit PreProgramming Msg



Press **ENTER** to Edit PreProgramming Msg ,
There are 99 PPG available.

2.7.1. Edit



Press **ENTER** when done

2.8. Clear All Data

**RESET DATABASE
ARE YOU SURE?**

If “YES”, by Pressing **ENTER**

If “NO”, by Pressing **ESC**

2.9. Protocol Type Selection

**Protocol Selection
Type: Programming
Speed: 19200
Mode: 8,n,1**

Press **ENTER** to link to computer.

**Operation
Disconnection
Press any key
TO Continue...**

Press any key to disconnect to computer

PS:

1. Have to select Protocol type in “Factory setting”.
2. You can select to
 1. GATAP, 2. Ipage2, 3. WaveWare, 4. Programming, 5. GACOMP2,
 6. POCSAG TEXT, 7. POCSAG NUMERIC, 8. COMP2, 9. COMP1,
 10. SCOPE

2.0. Frequency Setting

**Frequency Setting
45450000Hz**

2.A. HeartBeat Setup

HeartBeat Setup :
HeartBeat ON/OFF
HeartBeat Duration
HeartBeat Baud

2.B Factory Setting

Enter Password

Enter Password
***** █

ENTER default password “ 1234567 ”

2.B. Factor Setup

FACTORY SETTING:
Delay Parameter
Status Setting
Preamble Add on
Wave output
Range Duration
Function Password
Setup Password
Digital B/R Test
UART Setting
Protocol Select
2 Tone Setting
PBX Setting
Prompt Recording
PBX & 2 Tone Test

2.B.1 Factor Setup

Prompt Recording

Prompt Recording:

Prompt	#1	Pec
Prompt	#2	Pec
Prompt	#3	Pec
Prompt	#4	Pec
Prompt	#5	Pec

Operation example:

- **A. *Call Alpha Pager:*** (Please Edit the pager first, you can refer to "Select option 1: Edit Pagers", Select Pager Type: Alpha type, enter capcode, select baud rate, set frequency, then, Save & Exit , you also need to edit PPG message - 01 - 99 sets)
 1. Dial extension #
 2. 2 ringer tones
 3. Please enter your pager # (3 digits, for example: 01# or 001)
 4. * PPG message no. #

- **B. *Call Numeric Pager:*** (Please Edit the pager first, you can refer to "Select option 1: Edit Pagers", Select Pager Type: numeric type, enter capcode, select baud rate, set frequency, then, Save & Exit)
 1. Dial extension #
 2. 2 ringer tones
 3. Please enter your pager # (3 digits, for example: 01# or 001)
 4. *Key in numbers then press # , In example:23468758 #

- **C. *Call Tone Only Pager:*** (Please Edit the pager first, you can refer to "Select option 1: Edit Pagers", Select Pager Type: Tone Only, enter capcode, select baud rate, set frequency, then, Save & Exit)
 1. Dial extension #
 2. 2 ringer tones
 3. Please enter your pager # (3 digits, for example: 01# or 001)